# FRC Programming Tasks List v0.2.0D

# Noah Sutton-Smolin Yousuf Soliman Kian Sheik

# September 4, 2013

# Contents

	0.1 Initial lesson	 			2
1	Basic Usage				2
_	1.1 DebugLog usage	 			2
	1.2 Utilizing the Global class				
	1.3 Understanding function timings				4
	210 Chackenang lancton than 50 to the termination of the termination o	 •	·	•	•
<b>2</b>	Sensor and Motor Usage				5
	2.4 Using raw motors with MotorLink	 			5
	2.5 Using and declaring sensors	 			6
	2.6 Task 06 - Using raw encoders and angles	 			6
	2.7 Task 07 - Using motors in conjunction with encoders	 			6
	2.8 Task 08 - Using the PneumaticsManager	 			7
_					_
3	Event Manager				7
	3.9 Task 09 - Single run events				7
	3.10 Task 10 - Single run events and their execution order				8
	3.11 Task 11 - Iterable Events				9
	3.12 Task 12 - Iterable events and cancellation				9
	3.13 Task 13 - Events and call stack order				9
	3.14 Task 14 - More using events to control robots (Optional)				10
	3.15 Task 15 - More using events to control robots (Optional)				10
	3.16 Task 16 - Self-reregistering events				10
	3.17 Task 17 - [Empty]	 	•		10
4	Listener Manager				11
_	4.18 Task 18 - Registering events with ListenerManager				
	4.19 Task 19 - Running ListenerManager callbacks				
	4.20 Task 20 - Setting up and running controllers				
	4.21 Task 21 - Creating an event for driving				
5	Event Sequencing				12
	5.1 Task 23 - Creating and using the EventSequencer				
	5.2 Task 23	 			13

This is a compilation of the introductory tasks for FRC (FIRST Robotics Competition) programming. Each of these tasks are to be completed in order. This introduction is designed to be as concise as possible, so **be sure to ask questions**.

## 0.1 Initial lesson

Don't be lazy.

Do things right the first time.

This is the imperative of the programmer.

Don't be lazy.

## 1 Basic Usage

## 1.1 DebugLog usage

## 1.1.1 Goal

Learn the use of DebugLog to write outputs to the console.

#### 1.1.2 Details

One should never use System.out.print\* to print console outputs. The reasons are varied, but we do this primarily because the outputs become cluttered, unreadable, and generally unusable.

DebugLog is a class designed to beautify outputs and make them readable. It does this by enforcing three things:

- 1. Log message severity, which can be filtered (which is useful for obvious reasons).
- 2. Log message timestamps, which do not normally come with system outs.
- 3. Log message sources, which show where a message actually came from. This is critically important when diagnosing software issues.

The severity levels in order are:

- 1. DebugLog.LVL\_ERROR: This is used when the program has encountered an error which will cause it to exit
- 2. DebugLog.LVL\_SEVERE: This is used when a part of the program cannot continue as requested.
- 3. DebugLog.LVL\_WARN: This is used when a part of the program may not function as intended, or or something has the possibilty to fail.
- 4. DebugLog.LVL\_INFO: This is used for important operating information only.
- 5. DebugLog.LVL\_DEBUG: This is used for debugging outputs which are temporary and/or infrequent.
- 6. DebugLog.LVL\_STREAM: This is used for constant outputs. For instance, controller positions are under the stream level. The difference between STREAM and DEBUG is critical; don't mix them up.

The RobotTemplate class is actually what's run by the FRC API, and it interfaces with the Global class. You should never modify the RobotTemplate class.

#### 1.1.3 Task

Write one output of each severity level to the console when teleop starts, in order, using the DebugLog class.

#### 1.1.4 Success

- 1. Each output is written to the console successfully.
- 2. No file has been modified except for the Global class.
- 3. Only the initializeTeleop() function in the Global class has been modified.
- 4. No System.out.\* files are used.

## 1.2 Utilizing the Global class

#### 1.2.1 Goal

Understand the function of the Global class with respect to shared resources and robot intialization.

#### 1.2.2 Details

The Global class is used to hold all global resources and contain initalization functions. These functions are wrapped to from RobotTemplate, which you are free to inspect, but not modify.

The static modifier must be used before all Global variables; if you do not know what the static modifier does, you are free to do research into it. However, in short, the static modifier makes it so that only one instance of a variable can exist in a class. This means any class resource can be accessed using [CLASSNAME]. [RESOURCENAME] instead of [INSTANCENAME].

With respect to our given setup, if we had a Jaguar (motor) in Global declared as: public static final Jaguar jag1 = new Jaguar(1,2); it can be accessed from anywhere in the code by using Global.jag1; however, if we declared it like so: public final Jaguar jag1 = new Jaguar(1,2); without the static modifier, then it could not be accessed using Global.jag1, which makes it an ineffective declaration for our purposes.

The Watchdog class is not something you should ever personally need to deal with, as it is handled by the system, but it is important to understand. The Watchdog makes sure that the robot's code hasn't stopped or frozen. The act of "feeding" the watchdog ensures that the FRC system does not automatically kill our robot. The Watchdog is called using: Watchdog.getInstance().feed();

This gets the current instance of the Watchdog from the Watchdog class (through the static getInstance() function), and feeds it.

#### 1.2.3 Task

Create a Jaguar in the Global class. Change its power in each of the initialize\* functions. Be sure to feed the Watchdog somewhere once.

## 1.2.4 Success

- 1. The power was successfully set in each initialization function.
- 2. Watchdog was fed once.
- 3. No file was modified except for Global.

## 1.3 Understanding function timings

## 1.3.1 Goal

Understand when the initialization functions are called in game.

#### 1.3.2 Details

The RobotTemplate class controls the timings in the Global class. You need to understand when and under which circumstances the functions in the Global class would be invoked.

- initializeRobot() is invoked once when the robot's code starts up.
- initializeDisabled() is invoked once when the robot enters the disabled state before and after the game.
- initializeAutonomous() is invoked once when the robot's autonomous phase is about to begin.
- initializeTeleop() is invoked once when the robot's teleoperated phase is about to begin.

Every robot task in-game will be handled by the EventManager. The initialization functions are only used to set up EventManager's sequencing so that everything else follows suit and makes sense.

- robotKill() is a predefined function which you can invoke when you wish to shut off the robot entirely. After invoking this method, the robot will need to be power cycled.
- robotStop() allows you to turn off the robot without disconnecting or disabling it.

#### 1.3.4 Success

You read this section, didn't you? Go read it again.

# 2 Sensor and Motor Usage

## 2.4 Using raw motors with MotorLink

#### 2.4.1 Goal

Learn how to use the MotorLink class to more efficiently interface with the Jaguars.

#### 2.4.2 Details

The MotorLink class was written with a primary purpose of simplifying the logic beind encoders (which measure the angle of wheels) and speed controllers (which control the rate that motors move). As such, all motors should be written using MotorLink.

It is important to understand how to declare a Jaguar, though, for this task. A Jaguar is a hardware link that's part of the FRC API which connects to a motor controller on the physical robot. One can control a motor through the Jaguar class.

The motor you will be creating will take one argument: a Jaguar. You can declare the Jaguar in-line. Explore the MotorLink class and its functions. Bear in mind that it has been stripped down from its full form, as Events have not been introduced yet, and the MotorSpeedControl (a class which controls the speed of a motor) requires events.

Motors can be given powers from [-1.0, 1.0]; anything out of range is invalid.

#### 2.4.3 Task

Declare a MotorLink as a static resource in Global. Set its power scalar to a valid value. Set the motor power.

#### 2.4.4 Success

- 1. The MotorLink is declared as a static resource.
- 2. The Jaguar is not declared as a static resource, and is instead consumed by MotorLink.
- 3. The power scalar and powers are set properly.

## 2.5 Using and declaring sensors

## 2.5.1 Goal

Declare sensors and use their values.

#### 2.5.2 Details

Sensors are primarily accessible through the frc3128.HardwareLink package. For instance, a gyroscope will use the GyroLink class (locaed in frc3128.HardwareLink.GyroLink) for communications.

GyroLink consumes a Gyroscope in its constructor.

## 2.5.3 Task

Declare a new GyroLink as a static Global resource. Print its value on teleop init.

#### 2.5.4 Success

- The GyroLink is declared properly.
- The Gyroscope is consumed by the GyroLink constructor.
- The value of the gyro is printed out when the robot initializes.

## 2.6 Task 06 - Using raw encoders and angles

#### 2.6.1 Goal

Create an encoder and read out its angle.

#### 2.6.2 Details

None.

## 2.6.3 Task

Encoders are devices which keep track of the angle of a given motor. The MotorLink class can be linked with an AbstractEncoder.

Create a MagneticPotEncoder and print out its raw angle on teleop init.

## 2.6.4 Success

- Only the MagneticPotEncoder is kept as a static resource.
- The raw angle is printed out using DebugLog at the appropriate level.

## 2.7 Task 07 - Using motors in conjunction with encoders

#### 2.7.1 Goal

Properly use raw encoders and their angles.

## 2.7.2 Details

AbstractEncoder is an abstract class which has two required functions: getAngle() and getRawValue(). There are two predefined implementations: GyroEncoder and MagneticPotEncoder.

There is a static function in frc3128.Util.RobotMath called normalizeAngle(); this function must be invoked on all angle values continuously, as it keeps the angle values to within normal range. We keep track of angles from 0 to 360 degrees.

## 2.7.3 Task

Create a new MotorLink using a MagneticPotEncoder. Read out the angle, and print the normalized value to the print stream.

#### 2.7.4 Success

- Create a MotorLink and associated AbstractEncoder and Jaguar.
- The AbstractEncoder and Jaguar are fully consumed by the MotorLink.
- The angle from the MotorLink is normalized and printed out.
- The print out uses DebugLog.

## 2.8 Task 08 - Using the PneumaticsManager

#### 2.8.1 Goal

Learn the uses of PneumaticsManager.

#### 2.8.2 Details

PneumaticsManager is a class designed to control the pneumatic air compression systems on the robot. The pneumatics system uses compressors and two-sided solenoids called Festos to control air flow.

The PneumaticsManager must be declared with a compressor. When a new piston is created, it returns a PistonID, which is a reference value used by the PneumaticsManager to handle piston movements.

#### 2.8.3 Task

Initialize the PneumaticsManager. Turn the compressor off, then on. Create a piston, and record the PistonID as a static global resource. Turn the piston forward, then flip its state, then reverse its polarity.

#### 2.8.4 Success

All tasks completed without error.

# 3 Event Manager

## 3.9 Task 09 - Single run events

## 3.9.1 Goal

Learn how and when certain events are executed, and how to trigger single-run events.

## 3.9.2 Details

The EventManager is a rather simple block of code which drives the entire robot. It takes Events, or small blocks of code, and runs them in the sequence they were queued.

An Event is an abstract class. If you don't know what abstract classes are, it is strongly suggested that you look up the documentation for them. An Event must be declared as a class. That means, to create an event, you must do the following:

If you do not have the execute() function, you will not be adhering to the Event abstract class, and NetBeans will barf errors in your face.

You can also declare an Event inline, but it must have an implementation.

You can also declare an Event inline, and directly queue it:

The Event has several critical functions:

- registerSingleEvent() will insert the Event into the EventManager's queue, and run it once before removing it.
- registerIterableEvent() will insert the Event into the EventManager's queue, and it won't be removed until it is cancelled directly (or the entire Event stack is dropped).
- registerTimedEvent(int msec) will create a new instance of a TimerEvent and register it as an iterable event. When the timer expires, the selected Event will be run. If you're going to call this function, it is highly recommended that you call prepareTimer() first.

That's it for starting events. For cancelling events:

- cancelEvent() will cancel the running event.
- cancelTimedEvent() will cancel the event's execution timer.
- cancelEventAfter(int msec) will cancel the event after a given amount of time.

The EventManager is called automatically in RobotTemplate. Do not modfiy RobotTemplate. Do not manually invoke the EventManager de-queueing function.

#### 3.9.3 Task

Create a single run event which will print out some text.

## 3.9.4 Success

- 1. The text is printed out using DebugLog and an Event.
- 2. No resources are kept longer than they are needed.

## 3.10 Task 10 - Single run events and their execution order

## 3.10.1 Goal

Understand the queue nature of the EventManager.

## 3.10.2 Details

The EventManager uses a FIFO (First In, First Out) queue. Events will be run in the order they are inserted in the queue.

## 3.10.3 Task

Create a program which will print out "Hello," then "World," then set a motor on (1,2) to 50% power.

#### 3.10.4 Success

- 1. No extraneous resources are kept.
- 2. DebugLog is used for printing.
- 3. The motor is created using MotorLink and is created as a global static resource.
- 4. The program will execute successfully.

## 3.11 Task 11 - Iterable Events

#### 3.11.1 Goal

Understand and use iterable events.

#### **3.11.2** Details

Iterable events are the same as single run events, but they are not deleted on the EventManager's cleanup step. This means they will run continuously unless cancelled expliitly.

#### 3.11.3 Task

Create a program which will print out "Hello" continuously. After 1.5 seconds, a separate event should print out "World".

#### 3.11.4 Success

- 1. No resources are kept which are not needed.
- 2. It operates as described above.

## 3.12 Task 12 - Iterable events and cancellation

#### 3.12.1 Goal

Understand and use iterable events.

#### **3.12.2** Details

Iterable events must be cancelled manually, otherwise they will not be cancelled.

## 3.12.3 Task

Create a program which will print out "Hello" continuously. After 1.5 seconds, a separate event should print out "World", at which point, the "Hello" event should stop printing.

## 3.12.4 Success

- 1. No resources are kept which are not needed.
- 2. It operates as described above.
- 3. After two seconds, the robot should still be able to support additional code.

## 3.13 Task 13 - Events and call stack order

## 3.13.1 Goal

Experiment with events and callback orders.  $\,$ 

## 3.13.2 Details

None.

## 3.13.3 Task

Create a program which will start by setting a motor on (1,2) to 50% power, then print out "Hello" continuously. Another event should stop the "Hello" event, then print out "World" and set the motor to 0% power.

#### 3.13.4 Success

- 1. Task as described.
- 2. No extraneous resources are kept.

## 3.14 Task 14 - More using events to control robots (Optional)

#### 3.14.1 Goal

Understand how events are used to control the robot.

#### **3.14.2** Details

None.

## 3.14.3 Task

Create a MotorLink global static resource with a motor on (1,2). After 500msec, set its power to 50%. After 1000msec, set its power to -50%. After 1500 msec, set its power to 0%.

## 3.14.4 Success

Completion of the above.

## 3.15 Task 15 - More using events to control robots (Optional)

## 3.15.1 Goal

Understand how events are used to control the robot.

## **3.15.2** Details

None.

## 3.15.3 Task

Create a piston (use irrelevant port numbers) and change its state twice over the course of two seconds.

## **3.15.4** Success

Completion of the above.

## 3.16 Task 16 - Self-reregistering events

## 3.16.1 Goal

Understand how single events can be sequenced with themselves to run an event a given number of times.

## **3.16.2** Details

None.

## 3.16.3 Task

Write an event which will execute four times, printing each time.

## **3.16.4** Success

Completion of the above.

## 3.17 Task 17 - [Empty]

Skip this section for the time being.

## 4 Listener Manager

## 4.18 Task 18 - Registering events with ListenerManager

#### 4.18.1 Goal

Understand how ListenerManager and how listener callbacks work.

#### 4.18.2 Details

ListenerManager associates strings and integers with events. When an event is registered with the ListenerManager, it must be given an associated string or integer, known as the "key."

When the key is invoked, the ListenerManager will go through the list and find all events with matching keys, then execute them in order. For example, let's say I have an event:

```
Event e = new Event() {
public void execute() {
Global.motFL.setSpeed(0.5);
}
}
```

The event obviously will set the power of motFL to 50%. Now, what if I want to do this when I press the X button? (For the purposes of this example, we're assuming the controller's event is already running)

```
ListenerManager.addListener(e, ''buttonXDown"); or:
```

```
ListenerManager.addListener(e, ListenerConst.BTN\_X\_DOWN); //better for clarity
```

The ListenerCosnt class contains most of the available Listener constants. This is critically important for the Listeners, as this greatly increases the clarity and consistency of what you're doing. For instance (and this has happened), one can make a typo in buttonXDown, but one cannot easily make a typo in ListenerConst.BTN\\_X\\_DOWN.

To call a Listener, one simply needs to call ListenerManager.callListener(); both a String and an int are acceptable arguments.

## 4.18.3 Task

Create an event, and register it to trigger when the string "test" is called.

#### 4.18.4 **Success**

Self-explanatory.

## 4.19 Task 19 - Running ListenerManager callbacks

## 4.19.1 Goal

Call back events appropriately

#### 4.19.2 Details

None.

## 4.19.3 Task

Create an event for "Hello", and event for "World", and register both of them under ListenerManager for the key "helloworld". Call the "helloworld" key after 1.5 seconds.

#### **4.19.4** Success

Program prints out "Hello World"

## 4.20 Task 20 - Setting up and running controllers

## 4.20.1 Goal

Understand how controllers interface with the program.

#### 4.20.2 **Details**

Controllers are all contained in frc3128.HardwareLink.Controller. They are always Events, and register themselves iterably when the constructors are run.

As an example, we'll look at XControl, which interfaces with an XBox 360 controller. Every iteration, XControl checks to see if the controller's state has changed, and if so, what has. This is critically important for two reasons: first, it saves time. The program will only run what needs to be run when it needs to be run. Second, it's cleaner; the controller runs in the background, and buttons can be easily interlaced with the running program.

Controllers require a port number; this goes back to the driver station.

Controllers should always be global resources.

#### 4.20.3 Task

Create an XBox controller (XControl) on port 1. Make it such that, when button X is pressed, the program will print out "hello" for 1.5 seconds, then stop. Make it such that, when button Y is pressed, the program will print out "world" for 1.5 seconds, then stop.

#### **4.20.4** Success

Success at the above.

## 4.21 Task 21 - Creating an event for driving

#### 4.21.1 Goal

Create an event for driving.

#### 4.21.2 **Details**

Drive events are not iterable events; instead, they are registered with ListenerManager and are called when controller updates occur.

#### 4.21.3 Task

Create a Drive event which runs on UPDATE\\_DRIVE and will set the power of a motLeft motor to the value of the Y axis on joystick 1. The drive event should also set the power of a motRight motor to the value of the Y axis on joystick 2.

#### **4.21.4** Success

Success at the above.

# 5 Event Sequencing

## 5.1 Task 23 - Creating and using the EventSequencer

## 5.1.1 Goal

Understand how EventSequencers are used, how they make your life easier, and how they're used for autonomous.

## 5.1.2 Details

EventSequencer is a class which runs events in a given sequence. This is incredibly useful for things like turning a piston on, then off after half a second.

The EventSequencer is most useful during autonomous, however. Since SequenceEvents define their own exit conditions, they are indefinitely versatile for use in autonomous; simply define an event, define when you consider the event complete, then move on to the next one. The entire autonomous program can be written this way.

The tools for sequencing events are in the frc3128. EventManager. EventSequencer package. A SequenceEvent is still an Event. A SingleSequence is still a SequenceEvent.

The EventSequencer is an iterable event which is run by the EventManager. SequenceEvents are always written to be single events, but have another abstract function: exitConditionMet(). When exitConditionMet() returns true, the event is stopped, and the EventSequencer moves on to the next event in the queue.

Each SequenceEvent has several internal functions, one of which is getRunTimeMillis(). This function is used to determine how long the event has been running, and is useful for exitConditionMet functions which depend on a certain amount of time.

A SingleSequence event is a special case of the SequenceEvent and is, for all intents and purposes, syntactic sugar. It provides an easy way to create an event which will run once and only once. Even though the EventSequencer requires a SequenceEvent, remember that a SingleSequence is *also* a SequenceEvent; that's the way inheritance works.

A SingleSequence's exitConditionMet() function reads:

```
/**
 * Exits immediately; will always return true.
 *
 * @return true
 */
public final boolean exitConditionMet() {return true;}
```

The EventSequencer works off FIFO, so whatever you register with it first will run first.

The EventSequencer will start when EventSequencer's startSequence() method is invoked. To run it more than once, one must resetSequence(). One can always stopSequence(). An EventSequencer is also an Event.

## 5.1.3 Task

Create an EventSequencer and add a Hello SingleSequence to it, as well as a World SingleSequence. Trigger the EventSequencer.

## 5.1.4 Success

Success at the above.

#### 5.2 Task 23

#### 5.2.1 Goal

Use alternate exit conditions.

#### 5.2.2 Details

None.

## 5.2.3 Task

Create a SequenceEvent and have it print out until it exits in 1.5 seconds. Trigger two other events after this

## You win!